IOn Cheat Sheet

EXPLANATION OF NOTATION

Bold Browser menus
[Brackets] Facepanel buttons
{Braces} Softkeys and direct selects

<Angle brackets> Optional keys

[Next] & [Last] Keys to be pressed & held simultaneously

DISPLAY FUNCTIONS

Press [Tab]...[Tab]... to change focus to the next displays
Hold [Tab] & press [#] to select / highlight a specific display
Press [Escape] or [Live] / [Blind] to close or exit a display
Hold [Shift] & press [Tab] to close all displays except Live and the

Playback Status display

Press [Format] for summary or table view

Hold [Data] & press [Focus], [Color], [Form], [Image] or [Intensity]

to expand or suppress parameter category information

PATCH A DIMMER

[Displays], {S3} Patch

Patch by channel mode

Press [Format] to switch to patch by address

[1] [At] [5] [Enter] - patches channel 1 to address 5.

[1] [Thru] [24] [At] [1] [Enter] - patches channels 1 thru 24 to addresses 1 thru 24, sequentially.

PATCH A MOVING LIGHT

[2] [Enter] {Type} {Manu} {ETC} {Revolution Wybron} {IM/RWM} [At] [11] [Enter] - patches an ETC Revolution fixture to channel 2, starting at address 11.

Use [Next] to get next available channel

SETTING CHANNELS AT LEVELS

[1] [+] [3] [At] [5] [Enter] - sets level of 50%. Use [0][5] for 5%

[1] [thru] [5] [-] [4] [Full] [Enter] - excludes channel 4

[2] [+] [5] [Enter] [level wheel]

[1] [Full] [Full]- takes channel 1 to Full / 100%

[2] [At] [At] - default level as established in Setup

[1] [thru] [4] [Out] - takes all channels to zero

[Sneak] [Enter] - restores all selected or highlighted channels with manual values to their background or home state

[Clear] [Sneak] [Enter] – clears the command line and restores all channels with manual values to their background or home state

CHANNEL CHECK

[1] [at] [70] {Channel Check} [Enter] - brings channel 1 to 70% intensity.

Press [Next] ... [Next] ... [Next] ...

RECORDING A CUE

[Record] <Cue> [n] [Enter]

[Record] <Cue> [Next] [Enter]

[1] [thru] [5] [Record Only] [3] [Enter]

[Record Only] selectively stores only manually set values, or values set by the keypad

Changing a cue's timing

[Record] <Cue> [n] [Time] [x] [Enter] - records cue n and sets up & down time. This sets all timing in the cue to x.

[Record] <Cue> [n] [Time] [x] [Time] [y]

[Enter] - specifies split up/down times

[Cue] [n] [Time] [y] [Enter] - sets timing for cue n to y.

[Cue] [n] [Shift] &[Color] [Time] [y] [Enter] - sets color timing for cue n to y.

Multiple instructions on one command line:

[Record] <Cue> [n] [Label] Name [Enter] [Record] <Cue> [1] [Time] [3][Time][4] [Label] Joe enters [Enter].

Deleting a cue

[Delete] <Cue> [n] [Enter].

Press [Enter] again to confirm.

Using Go To Cue

[Go To Cue] [0] [Enter] - sets all intensity values to zero for the selected cue list

[Go To Cue] [Out] [Enter] - resets all parameters to their default state and resets all cue lists active on faders to the top of their cue list.

[Go To Cue] [5] [Enter]
[Go To Cue] [Next] or [Last] [Enter]



IOn Cheat Sheet

SUBMASTERS

Recording to a submaster

[Record] [Sub] [5] [Enter] - records the current stage state to sub 5.

[Record], then press both buttons under the sub - loads the fader with the submaster

[Record Only] [Sub] [5] [Enter] - records the manual intensities of the current stage state

[Sub] [4] [Time] [3] [Time] {Hold} [Time] [3] [Enter] adds a 3 sec up time, a 'hold' dwell time, and a 3 sec down time

[Sub] [Sub] opens the submaster list

Changing pages of submasters

Press and hold **[Fader Controls]** and press the lower bump button of the sub displaying the page that you want

Clearing a submaster

[Shift], then press both buttons under the sub - clears the fader of the contents

[Delete] [Sub] [5] [Enter] [Enter] - deletes sub 5 entirely

GROUPS

[1] [thru] [8] [Record] [Group] [5] [Enter] records selection to group 5

[Record Only] [Group] [5] [Enter] - records the manual intensities of the current stage state to group 5.

[Group] [5] [Enter] - selects group 5. [Group] [Group] opens the Group List

PALETTES AND PRESETS

Palettes & presets are referenced data. Four palette types: Intensity, Focus, Color, Beam. A reference that includes a mix of categories is a Preset.

[Record] [Focus Palette] [1] [Enter] - stores all focus values for any channels that have non-default focus parameters to FP 1.

[Record Only] [Color Palette] [3] [Enter] - stores only manual color palette data to color palette 3.

[Group 5] [Beam Palette] [5] - sets the channels in group 5 to Beam Palette 5.

[Displays] {Color Picker} - opens the color picker.

SAVING A SHOW

Quick Save

Hold [Shift] and press [Update].

Press [Displays] or click in the Browser

To save the show you are working on, **File> Save>** and press [Select].

To create a new show file, **File> New>** and press [**Select**].

To save an existing show to a different location or with a different name, File> Save As> and press [Select].

EFFECTS (CHASES)

Using Preprogrammed Effects

[1] [Thru] [10] [Effect] [915] [Enter] - intensity will ramp up and down for channels 1 thru 10

Creating a Step Effect

[Effect] [Effect] opens the Effects List

[1] [Enter] sets the effect number

<Type> {Step-based} assigns the effect as a step effect

(Step) [1] [Thru] [6] [Enter] defines the number of steps

[Page▶] or right arrow over to the Channel column

[1] [thru] [12] [Enter] specifies the channels

Use page arrows to access "Step time". Enter the desired step time: [1]

Page arrow to the In Time column and enter a dwell time: [1]

Page arrow to the Dwell Time column and enter a dwell time: [1]

Page arrow to the Decay Time column. Enter a decay time: [.] [25]

Page arrow to the On State column and enter the percentage: [100]

Page arrow to the Off State column and enter the percentage: [5]

Adjust any of the other attributes from the CIA by pressing or clicking on the appropriate detail button in the properties display and making changes

[Live]...[1] [Thru] [12] [Effect] [1] [Enter] – runs the effect on channels 1 thru 10